



SKM311 LINERIDER ITEM-NO AND DESCRIPTIONS

PART NUMBER	DESCRIPTION
031-300-101-176	SENSOR ASSY, SKM311 1/2", E133
031-300-101-184	SENSOR ASSY, SKM311 5/8", E133
048-311-060-001	SENSOR, LINERIDER SKM311 1/4" (6-9mm) W/MOUNTING ARM
048-311-060-002	SENSOR, LINERIDER SKM311 1/2" (10-13mm) W/MOUNTING ARM
048-311-060-003	SENSOR, LINERIDER SKM311 5/8" (13-16mm) W/MOUNTING ARM

PAT PAT EQUIPMENT CORPORATION 1665 ORCHARD DRIVE CHAMBERSBURG, PA 17201		GENERAL TOLERANCES X.XX = 0.01 X.XXX = 0.005		SKM311 LINERIDER	
				SPARE PARTS LIST	
REV	ECN	DESCRIPTION	BY	APV	DATE
A	980141	CORRECT ITEM 5 - QTY 1	CSH	CSH	06/03/98
<small>PAT Equipment Corporation reserves proprietary rights to this drawing and to the data shown thereon. The drawing and data are confidential and are not to be used or reproduced without the written consent of PAT Equipment Corporation. This drawing is subject to technical modification without prior notice.</small>			SCALE: NONE		SHEET: 1 OF 2
C.A.G.E. 79760			SIZE DWG NO.		REV
A			980101		A 048 311 02 0001 A



DWG NO. 048 311 02 0001 REVISION A

PAGE 2 OF 2

PART NO. SEE PAGE 1 FOR SKM311 PART NUMBERS
SKM311 PARTS LIST

NO.	PART NO.	QTY	DESCRIPTION
01	000-330-700-500	1	Sensor Accy, Load Beam SKM311/312, 500 Kilo.
02	048-312-100-003	1	Sensor Accy, Amplifier SKM311/312 4 Pin W/Housing
02	048-312-100-004	1	Sensor Accy, Amplifier SKM311/312 3 Pin W/Housing
03	031-300-110-050	2	Screw, 4mm X 40 Skt. Cap (S.S)
04	048-311-110-002	1	Sheave Set, SKM 311, 1/2" Line Rider (10-13mm) #37
04	048-311-110-003	1	Sheave Set, SKM 311, 5/8" Line Rider (13-16mm) #38
05	031-300-110-060	1	Sensor Accy, SKM311 Bushing Between Sideplates
06	031-300-100-618	8	Hardware, Retaining Ring, Ext- Ternal 12mm
07	031-300-110-051	3	Sensor Accy, SKM311, Bolt For Sheave 10mm X 70 Hex(S.S)
08	031-300-110-052	4	Sensor Accy, SKM311 Nut 10mm Hex For Sheave Bolt
09	031-300-110-053	4	Sensor Accy, SKM311 Washer 10 Mm Belville Z/P
10	031-300-110-054	1	Sensor Accy, SKM311 Bolt For Ctr. Sheave 10mm X 46 Hex
11	031-300-110-055	1	Sensor Accy, SKM311 Pin, Load Indicator, .471 Od.X2.210 Lg
12	031-300-110-056	2	Sensor Accy, SKM311 Bushing For Guide Pin
13	031-300-110-057	1	Sensor Accy, SKM311 Guide Pin Line Bkt. 0.392X2.210
14	031-300-110-058	1	Sensor Accy, SKM311 Bracket Line Location For Mtg. Arm
15	031-300-110-059	1	Sensor Accy, SKM311 Side Plate Set (Only Sold As A Set)
16	000-304-000-200	4	Sensor Accy, SKM311 Rubber Bumper
17	031-300-110-061	1	Sensor Accy, SKM311 Frame Load Cell Mtg.
18	048-311-100-002	1	Sensor Accy, SKM311 Mtg. Pole, Linerider
19	031-300-110-062	1	Sensor Accy, SKM311 Nut 12mm-1.5 Hex, Stainless Steel
20	031-300-110-063	1	Sensor Accy, SKM311 Washer 12m M Belville
21	031-300-110-064	1	Sensor Accy, SKM311 Screw 12mm -1.5 X 47mm Flat-2 Sides
22	031-300-110-065	1	Sensor Accy, SKM311 Plate Load Cell Hold Down 55X30X4mm