



DWG NO. 050 350 06 1202 REVISION A
PAGE 2 OF 2
PART NO. 050-350-061-202
DS350 CONSOLE LATTICE; PARTS LIST

NO.	PART NO.	QTY	DESCRIPTION
1	050-350-101-202	1	FRONT PANEL
2	050-000-100-043	1	SWITCH, DECADE 3 – 0 TO 9 POSITION
3	050-350-300-042	1	BOARD, MAIN DS350 CONSOLE
4	050-350-300-006	3	BOARD, DISPLAY
5	031-300-110-123	3	BOARD, ILLUMINATION 24V DS350 LATTICE SMALL DISPLY
6	005-035-030-009	3	BOARD, ILLUMINATION 12V DS350 LATTICE SMALL DISPLY
7	050-350-110-140	1	SWITCH, ROTARY, GEOMETRY SELECTION, 16 POSITION
8	050-350-110-153	1	SWITCH, ROTARY, REEVING, 1-15 N POSITION
9	000-323-010-525	1	ALARM BUZZER
10	050-350-110-001	1	INDICATOR, ANALOG METER,(GREEN -YELLOW-RED)
11	000-312-043-141	3	LAMP ACCY, BASE LMI CONSOLE W/NO PUSHBUTTON
12	050-350-110-073	1	SWITCH ACCY, LENS CAP, YELLOW (PREWARNING)
13	050-350-110-075	1	SWITCH ACCY, LENS CAP, RED (STOP)
14	050-350-110-074	1	SWITCH ACCY, LENS CAP, RED (A2B)
15	000-311-023-128	7	LAMP, 28V, LUMITAS
16	000-311-023-114	7	LAMP, 14V, LUMITAS
17	000-305-043-423	2	SWITCH, PUSHBUTTON, CONSOLE, DS350
18	050-350-110-079	1	SWITCH ACCY, LENS CAP, GREEN (BUZZER OFF)
19	050-350-110-044	1	SWITCH ACCY, LENS CAP, YELLOW (TARE)
20	050-350-110-116	1	STRAIN RELIEF ASSY, PG 13.5 RED, W/NUT+WASHER
21	050-350-110-117	1	KNOB ASSY, MOUNTING FOR DS350 CONSOLE BRACKET